



Carbon Fibre Engine Cover Handling



Remove the original rubber mounting grommets from the OEM engine cover.

Fit the rubber mounting grommets to the new Forge Motorsport carbon fibre engine cover.

Lubricate the rubber mounting grommets (we recommend either silicone spray or hot soapy water).

Position the carbon fibre engine cover making sure the rubber grommets are lined up with the mounting pegs.

Place your hands over the mounting pegs (as they are the strongest point), push the cover down into position gently and smoothly.

When removing the carbon cover place your hand under the cover where the mounting grommet is located and pull upwards in a gentle and smooth action.

During fitting or removal, **DO NOT** push or pull on the edges of the engine cover as this could damage the product.

Forge Motorsport accept no responsibility for damage caused by improper use or installation of our products.

info@forgemotorsport.co.uk
www.forgemotorsport.co.uk
[@forgemotorsport](https://www.instagram.com/forgemotorsport)



PLEASE READ INSTRUCTIONS AND/OR CHECK WITH YOUR CHOSEN RETAILER BEFORE INSTALLATION. IF NOT INSTALLED CORRECTLY DAMAGE TO YOUR ENGINE/VEHICLE MAY OCCUR



BITTE LESEN SIE BENUTZERHINWEISE UND / ODER KONTROLLE IHR CHOSEN INSTALLATEUR VOR INSTALLATION. WENN NICHT INSTALLIERT, KORREKTE SCHÄDEN MOTOR / FAHRZEUG KANN AUFTRETEN



POR FAVOR DE LEER LAS INSTRUCCIONES O VERIFICAR CON NUESTRO DISTRIBUIDORES ANTES DE LA INSTALACIÓN. SI NO ES INSTALADO CORRECTO PUEDE QUE SU MOTOR CORRA PELIGRO DE DAÑOS.



請在安裝前詳閱安裝說明書或與當地的經銷商聯絡確認安裝細項。如未按照正確步驟安裝可能會造成車輛軟硬體損失