



FMINLH13 Fitting Instructions



Please thoroughly read through and familiarise yourself with these instructions in their entirety prior to beginning any part of the installation process of any component. Please also ensure the vehicle and engine has cooled down sufficiently to avoid risking possible skin burns or other injury.

1. If your vehicle has the moisture sensor arrowed below before removing the OEM inlet hose depress the latches on the wiring loom that connects to the moisture sensor and disconnect. This loom can now be tucked away neatly to avoid it being earthed on a metal component the loom should also be not fixed to the turbo or large heat source. The loom does not need to be connected.

