




## Toyota Supra strut brace fitting instructions (**FMSB1**)



**Please thoroughly read through and familiarise yourself with these instructions in their entirety prior to beginning any part of the installation process of any component. Please also ensure the vehicle and engine has cooled down sufficiently to avoid risking possible skin burns or other injury.**

### **TOOLS NEEDED:**

- 10MM Socket and suitable drive
- 6MM Allen Key
- 8MM Allen key

1. Loosely place the strut bars in position ensuring the correct hand is located on the correct side and place the bolts in position. Using your 8mm Allen key tighten the M10 Allen cap first.



2. Located in the inner wheel arch where the strut mounts to the body, you will see the 8mm Allen Cap protruding through the strut top. Place the washer and Nyloc nut on the bottom of the fastener. Using a 10mm socket and suitable drive, hold the nut in position and tighten the Allen Cap using a 6mm Allen key from above.



3. The M10 Fastener may now be torqued to 42NM and the M8 Fastener may be torqued to 20NM.