

Set Includes:

- Rear Side Splitters 1set
- 8x bolt M6
- 8x washer M6
- 8x nut M6
- Installation manual



1. Check fitting:

Line up splitter's edge with bumper edge near wheels, fit second edge to the bumper.


1.



2. Install spoiler:

After fitting splitters, drill holes through bumper and rear side splitters, insert screws and tighten the nuts.

2.



3. Repeat point 2 for the other side.

3.

