



034MOTORSPORT DENSITY LINE ADJUSTABLE UPPER CONTROL ARM KIT, TRACK SPEC, B5/B6/B7/C5 AUDI A4/S4/RS4 & A6/S6/RS6

[034Motorsport Density Line Adjustable Upper Control Arm
Kit, Track Spec, B5/B6/B7/C5 Audi A4/S4/RS4 & A6/S6/RS6 -
034-401-1063](#)



These control arms are perfect for those who track their cars and are looking for adjustability to dial-in more negative camber for improved front end cornering grip, improved feel, and better control of suspension geometry from higher durometer inner rubber bushings.

About This Guide

This Assembly Guide documents the process of the proper configuration prior to installation with the 034Motorsport parts that you have just purchased! Pictures and part numbers may vary, but the process remains the same.

Getting Started

- Confirm you have received all of the parts included with your purchase, if there are missing components, please contact customerservice@034motorsport.com

Collect the necessary tools required for installation by reading the complete Assembly Guide.

Supplied Parts:

- (4x) billet control arms with bushings installed
- (4x) spherical heim joints with jam nuts
- (4x) dust boots
- (4x) washers
- (4x) M10 screws
- (4x) pins
- (2x) packets of anti-seize
- (1x) packet of Loctite

Tools Needed:

- (2x) capable hands
- M6 Allen



Step A

Open hardware packages



Step B

Slide pin into heim joint



Step C

Install washer onto the back of the pin and install screw to hold the washer in place. No Loctite yet

**Step D**

Apply half packet of anti-seize to spherical heim joint



Step E

Run the jam nut down the shaft to disperse the anti-seize along the entire threaded portion



Step F

Leave about 8 threads exposed from the 'bottom' of the shaft



Step G

Install the heim joint into the billet arms, leaving about
8 threads exposed

**Step H**

The car will need to be aligned to set the final length



Step I

Once the alignment is complete, apply blue Loctite to M10 button-head screws.

**Step J**

Torque to 25 Nm with a 6mm Allen

