


CTSBM004.2 BMW Steering Wheel Control Interface





Vehicle Application

BMW 3 Series (E46) 1998 - 2005 BMW 5 Series (E39) 2000 - 2004 BMW Z4 (E85) 2002 - 2008 BMW Mini (R50/R52)* 2001 - 2006 BMW X5 (E53) 2000 - 2006 *i-Bus Vehicles (Pre CAN-Bus)

Key Features

- Retains Steering Wheel Controls
- Retains Factory Phone Buttons





The information provided in this document is subject to change without notice due to changes and/or improvements to the product/s.

ABOUT THIS PRODUCT

CTSBM004.2

Analogue Steering Wheel Control Interface for BMW vehicles with BMW Business OEM stereos and Quadlock connectors. Retains steering wheel controls and factory phone buttons.

WIRING COLOUR CODES

Purple Purple/Black Green Green/Black Grey Grey/Black White	Right Rear Speaker + Right Rear Speaker - Left Rear Speaker + Left Rear Speaker - Right Front Speaker + Right Front Speaker + Left Front Speaker +	Yellow Black Red	Permanent 12V Ground Ignition 12V
White/Black	Left Front Speaker -		

PRIOR TO INSTALLATION

Read the manual prior to installation. Technical knowledge is necessary for installation. The place of installation must be free of moisture and away from heat sources. Please ensure that the correct tools are using during the installation to avoid damage to the vehicle or product. **Connects2 can not be held responsible for the installation of this product.**

TECHNICAL SUPPORT

Connects2 Ltd. want to provide a fast and suitable resolution to any problems encountered during installation of this product. To get in touch with our dedicated technical support team, please fill in a ticket at **support.connects2.com** and provide as much information as possible.



FITTING GUIDE

1. Remove and disconnect the original head unit.

2. Connect the 12 way molex connector of the head unit patch lead (supplied separately) to the interface.





3. Connect the opposite end of head unit patch lead to the head unit steering wheel control input on the back of the aftermarket head unit.

NB: This may be a 3.5mm jack plug or a wire input depending upon the head unit brand being fitted. Please see the head unit installation manual for further information on where to connect.

Important: This step must be completed before connecting power to the interface. Failure to so do may result in no steering wheel control function.



4. Connect the 14 way molex connector to the interface



5. Connect the male power/speaker ISO harness to the female power/speaker ISO harness from the aftermarket head unit. For aftermarket head units without an ISO connector, please refer to "Wiring Colour Codes" on Pg. 2.



www.connects2.com

FITTING GUIDE

6. Connect the female vehicle specific connector on the harness to the male vehicle connector from the vehicle. Test head unit for correct operation.

STEERING WHEEL CONTROL FUNCTIONALITY

Original ButtonFunctionPlus IconVolume +Minus IconVolume -Up ArrowTrack +Down ArrowTrack -R/TPick UpSpeechHang Up (Mute if Hang Up Not Supported)

Example Steering Wheel Control Configuration

(Actual configuration may differ depending on vehicle model)

